




POWER BANK

INSTRUCTIONS


Model: BRIO 3500



User Manual

1

Product Overview



Specification

Input: DC 5V, 1A max
 Output: DC 5V, 1A max
 Dimension: 4.6"x 2.6"x0.3" (116x66x8mm)
 Weight: 165g
 Operating Temp.: 14°F to 113°F(-10°C to 45°C)
 *Design and specifications are subject to change without notice.

LED Power Status

LED Indicator (● ON ○ OFF)	Capacity
●●●●	75%~100%
●●●○	50%~75%
●●○○	25%~50%
●○○○	0%~25%
○○○○	0%



2

Charging Time

Built-in Battery	Charging Time
3.7V (typ.3500mAh)	Approx 3-4 hours (from standard USB port)

*Charging time vary from charging current.

Supply Time


USB output port	Supply Time
5.0V/1A (max)	Approx. 2-3 hours <small>Time depends on charge</small>

*Supply time vary from brands, model, and operation mode.

Directions

Input: to charge the power bank

*The Micro USB Port is for DC input
 *The standard USB Port is for DC output.




3

- 1.Connect the Micro USB connector of the supplied USB cable to the Micro USB input.
- 2.Connect the other end of the supplied USB cable to computer USB port or to your USB adaptor with standard USB.
- 3.LED light will turn on one by one when it's charging.

Output: to charge the smartphone or portable devices


*The Micro USB Port is for DC input
 *The standard USB Port is for DC output.



- 1.Connect the standard USB connector to the USB output port of the power bank.
- 2.Connect the Micro USB connector of the supplied USB cable to the portable device(for devices without Micro USB port, please use relevant adaptor).
- 3.Turn the power bank on and the charging will start.

4

Contents of Packing



1x 3500mAh Power Bank
 1X USB Connector Set
 1X User Manual

Warning

- Do not adjust the output voltage higher than device voltage, which will cause device damage.
- Use the specified charger.
- Avoid short circuit, disassembling and throwing into fire.
- Do not disassemble or modify the charger or power bank.
- Keep away from moisture,water.
- Do not drop, place heavy weight on, or allow strong impact to this product.
- Do not expose this product to direct sunlight or water.
- Do not touch the joining terminals directly or insert your fingers into them.
- Children use the product under the guidance of adults.
- While in use, do not cover this product with materials such as blankets.
- Keep the contact surface clean.
- Charge the power bank away from a TV, radio, or tuner as noise may occur.
- Refer to the user manual when operating the portable device.

*Power bank may become hot when charging.This is normal.Use caution when handling.

5

Warranty Card

A2batt.Inc warrants this product against defects in workmanship or materials for a period of 12 months from the original date of purchase of the product(at the point of sale) or from the receipt of shipment(from online and mail orders).

The warranty is valid except in the following conditions:

- 1.No warranty card or purchase invoice.
 - 2.Damages caused due to disobeying the user manual.
- During the warranty period, any malfunction caused by the quality problem, please contact the service center or authorized agent with original packaging, warranty card & purchase invoice to get repair, replacement or refund.

Customer's Information

Customer's name	
Telephone	
Address	
Product name	
Model No.	
Serial No.	
Purchase date	
Seller	
Maintenance record	

Designed by A2batt, Inc in CA, USA. Assembled by EEMB' China.
 A2batt, Inc
 1960 Essex Ct Redlands,
 Redlands, CA 92373 USA (909)-798-8700
 Visit us at www.monerator.com
 E-mail:global@monerator.com

6